

## PL77/L77F-UAH10

### PL77/L77F DIP SWITCHES SETTING : 1(Pulse/ccTalk/ICT104U)

Supported bill HRYVEN 1, 2, 5, 10, 20, 50, 100, 200, 500, 1000 10bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	OFF	OFF	OFF							
	2 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	OFF	OFF	ON							
	3 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	OFF	ON	OFF							
	4 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	OFF	ON	ON							
	5 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	ON	OFF	OFF							
	10 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	ON	OFF	ON							
	20 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	ON	ON	OFF							
	100 Pulse / HRYVEN 1 & 5 <small>(Note.4)</small>	ON	ON	ON							
	Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★	Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept HRYVEN 1 & 2 <small>(Note.4)</small>				ON						
	Reject HRYVEN 1 & 2 <small>(Note.4)</small>				OFF						
★	Accept HRYVEN 5 & 10				ON						
	Reject HRYVEN 5 & 10				OFF						
★	Accept HRYVEN 20 & 50				ON						
	Reject HRYVEN 20 & 50				OFF						
★	Accept HRYVEN 100 & 200				ON						
	Reject HRYVEN 100 & 200				OFF						
★	Accept HRYVEN 500 & 1000				ON						
	Reject HRYVEN 500 & 1000				OFF						

★ Manufacture setting

Note:(1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip Switch 1 to 5 are only for Pulse mode.

(3) Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

(4) Pulse Mode:

Dip 6 turn ON ,One Pulse per HRYVEN 1.

Dip 6 turn OFF,One Pulse per HRYVEN 5.

## PL77/L77F-UAH9(Pulse/ccTalk/ICT104U)

### DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ccTalk Interface		OFF	OFF	
	ICT104U Mode		ON	ON	
	Reserved		OFF	ON	
★	Reserved			ON	
				OFF	

★ Manufacture setting

### DIP SWITCHES SETTING : 2(ccTalk)

	FUNCTION	SW1	SW2	SW3	SW4
	8-bit checksum	ON			
★	CRC 16-bit checksum	OFF			
	Pulse Mode		ON	OFF	
★	ccTalk Interface		OFF	OFF	
	ICT104U Mode		ON	ON	
	ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
★	Encryption Mode			ON	
	Decrypt Mode			OFF	

★ Manufacture setting

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

### DIP SWITCHES SETTING : 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
	ccTalk Interface		OFF	OFF	
★	ICT104U Mode		ON	ON	
	Reserved		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

### Currency Assign Data

Interface Bill value	Pulse		ICT104U	ccTalk
	Dip 6 is ON	Dip 6 is OFF		
BV1	1	5	1	1
BV2	2	10	2	2
BV3	5	20	5	5
BV4	10	50	10	10
BV5	20	100	20	20
BV6	50	200	50	50
BV7	100	500	100	100
BV8	200		200	200
BV9	500		500	500
BV10	1000		1000	1000