

L83-KGS8

L83 Option Switch Settings : 1(Pulse/MDB/ccNet)

Supported bill KGS 20, 50, 100, 200, 500, 1000, 2000, 5000 8bills.

L83 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / KGS 10	OFF	OFF	OFF							
2 Pulses / KGS 10	OFF	OFF	ON							
3 Pulses / KGS 10	OFF	ON	OFF							
4 Pulses / KGS 10	OFF	ON	ON							
5 Pulses / KGS 10	ON	OFF	OFF							
10 Pulses / KGS 10	ON	OFF	ON							
20 Pulses / KGS 10	ON	ON	OFF							
100 Pulses / KGS 10	ON	ON	ON							
Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★ Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept KGS 20 & 50						ON				
Reject KGS 20 & 50						OFF				
★ Accept KGS 100 & 200							ON			
Reject KGS 100 & 200							OFF			
★ Accept KGS 500 & 1000								ON		
Reject KGS 500 & 1000								OFF		
★ Accept KGS 2000 & 5000									ON	
Reject KGS 2000 & 5000									OFF	
Simulation Bill Box Has Been Removed										ON
★ Default										OFF

◆ Manufacture Default setting.

Note : (1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip Switch 1 to 5 are only for Pulse mode.

(3) MDB Mode:

When Dip 6 is OFF,Accept KGS 5000.

When Dip 6 is ON ,Reject KGS 5000.

L83-KGS8(Pulse/MDB/ccNet)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Interface		ON	OFF	
MDB Interface		ON	ON	
ccNet Interface		OFF	OFF	
Reserved		OFF	ON	
Reserved				ON
★				OFF

★ Manufacture setting

Interface Settings: 2(ccNet)

INTERFACE	SW1	SW2	SW3	SW4
19200 baud Rate	ON			
★ 9600 baud Rate	OFF			
Pulse Interface		ON	OFF	
MDB Interface		ON	ON	
★ ccNet Interface		OFF	OFF	
Reserved		OFF	ON	
Reserved				ON
★				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse	ccNet	MDB	
			When Dip 6 is OFF	When Dip 6 is ON
BV1	KGS 20	KGS 20	KGS 100	KGS 20
BV2	KGS 50	KGS 50	KGS 200	KGS 50
BV3	KGS 100	KGS 100	KGS 500	KGS 100
BV4	KGS 200	KGS 200	KGS 1000	KGS 200
BV5	KGS 500	KGS 500	KGS 5000	KGS 500
BV6	KGS 1000	KGS 1000	KGS 2000	KGS 1000
BV7	KGS 5000	KGS 5000		
BV8	KGS 2000	KGS 2000		KGS 2000

Interface Settings: 2(MDB)

INTERFACE	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Interface		ON	OFF	
★ MDB Interface		ON	ON	
ccNet Interface		OFF	OFF	
Reserved		OFF	ON	
Reserved				ON
★				OFF

★ Manufacture setting