

L83-RSD8

L83 DIP SWITCHES SETTING : 1(Pulse/RS232 A0/ccTalk)

Supported bill RSD 10, 20, 50, 100, 200, 500, 1000, 2000 8bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / RSD 10	OFF	OFF	OFF							
2 Pulses / RSD 10	OFF	OFF	ON							
3 Pulses / RSD 10	OFF	ON	OFF							
4 Pulses / RSD 10	OFF	ON	ON							
5 Pulses / RSD 10	ON	OFF	OFF							
10 Pulses / RSD 10	ON	OFF	ON							
20 Pulses / RSD 10	ON	ON	OFF							
100 Pulses / RSD 10	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms				ON						
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept RSD 10 & 20						ON				
Reject RSD 10 & 20						OFF				
★ Accept RSD 50 & 100							ON			
Reject RSD 50 & 100							OFF			
★ Accept RSD 200 & 500								ON		
Reject RSD 200 & 500								OFF		
★ Accept RSD 1000									ON	
Reject RSD 1000									OFF	
★ Accept RSD 2000										ON
Reject RSD 2000										OFF

★ Manufacture setting

Note: 1. Please reset the bill acceptor after any changes on Dip switch.

2. Dip Switch 1 to 5 are only for Pulse mode.

3. Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

L83-RSD8(Pulse/RS232 A0/ccTalk)

DIP SWITCHES SETTING : 2(Pulse)

Currency Assign Data

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
RS232 A0 Mode		ON	ON	
Reserved				ON
				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
8-bit checksum	ON			
★ CRC 16-bit checksum	OFF			
Pulse Mode		ON	OFF	
★ ccTalk Interface		OFF	OFF	
ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
RS232 A0 Mode		ON	ON	
Encryption Mode				ON
★ Decrypt Mode				OFF

★ Manufacture setting

Note: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING : 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
★ RS232 A0 Mode		ON	ON	
Reserved				ON
				OFF

★ Manufacture setting

Interface Bill value	Pulse	RS232 A0	ccTalk
BV1	RSD 10	RSD 10	RSD 10
BV2	RSD 20	RSD 20	RSD 20
BV3	RSD 50	RSD 50	RSD 50
BV4	RSD 100	RSD 100	RSD 100
BV5	RSD 200	RSD 200	RSD 200
BV6	RSD 500	RSD 500	RSD 500
BV7	RSD 1000	RSD 1000	RSD 1000
BV8	RSD 2000	RSD 2000	RSD 2000

RS232 A0 INFORMATION	
BillType Data	
Code	Denomination
1	RSD 10
2	RSD 20
3	RSD 50
4	RSD 100
5	RSD 200
6	RSD 500
7	RSD 1000
8	Reserved
9	RSD 2000