XBA-BGN11(BGN5+EUR6) Option Switch Settings

Supported bill   BGN 2, 5, 10, 20, 50   5bills.
**   €   5, 10, 20, 50, 100, 200   6bills.**

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Reject BGN 2 & 5 & 10	ON							
★ Accept BGN 2 & 5 & 10	OFF							
Reject BGN 20 & 50		ON						
★ Accept BGN 20 & 50		OFF						
Reject € 5 & 10			ON					
★ Accept € 5 & 10			OFF					
Reject € 20 & 50				ON				
★ Accept € 20 & 50				OFF				
★ Reject € 100(2019) & 200(2019)					ON			
Accept € 100(2019) & 200(2019)					OFF			
Disable Bill Reject 4 Times BA Stop By 30 Sec						ON		
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF		
Stack Banknote when Power-up							ON	
★ Reject Banknote when Power-up							OFF	
Reserved								ON
★ Reserved								OFF

★ Manufacture setting

Currency Assign Data

Interface / Bill value	ICT104U	GPT	ICT104V	Pulse	MDB
BV1	BGN 2	BGN 2	BGN 2	BGN 2	BGN 2
BV2	BGN 5	BGN 5	BGN 5	BGN 5	BGN 5
BV3	BGN 10	BGN 10	BGN 10	BGN 10	BGN 10
BV4	BGN 20	BGN 20	BGN 20	BGN 20	BGN 20
BV5	BGN 50		BGN 50	BGN 50	BGN 50
BV6	€ 5		€ 5	€ 5	€ 5
BV7	€ 10		€ 10	€ 10	€ 10
BV8	€ 20		€ 20	€ 20	€ 20
BV9	€ 50		€ 50	€ 50	€ 50
BV10	€ 100		€ 100	€ 100	€ 100
BV11	€ 200		€ 200	€ 200	

This dip switch is located at the side of XBA.

(2)

DIP Switch

Appendix

XBA-BGN11 (Pulse/MDB/ICT104U/GPT/ICT104V)

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Inhibit Active HIGH	ON							
★ Inhibit Active LOW	OFF							
Reserved		ON						
★ Reserved		OFF						
Reserved			ON					
★ Reserved			OFF					
Reserved				ON				
★ Reserved				OFF				

	Pulse Mode	MDB Mode	ICT104V Mode					
★	Credit-Pulse Normal HIGH	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	Connect with coin changer	ON				
	Credit-Pulse Normal LOW	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	Connect with ICT VCCS converter board	OFF				

			SW6	
★ Pulse Mode			ON	
Other Mode			OFF	

	Pulse Mode	Other Mode	SW7	SW8
★	1 pulse / BGN 1	MDB Mode	OFF	OFF
	5 pulse / BGN 1	GPT Mode	OFF	ON
	10 pulse / BGN 1	ICT104U Mode	ON	OFF
	20 pulse / BGN 1	ICT104V Mode	ON	ON

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note： (1) Please reset the bill acceptor after set the dip switch.
(2) Dip switches 1 to 5 are only used for pulse protocol.
(3) calibrate card
(4) The transaction Record can be saved by USB MSD (only for EX series)
(5) EUR   5 display BGN   10 (Only for Pulse, MDB)
   EUR 10 display BGN   20 (Only for Pulse, MDB)
   EUR 20 display BGN   40 (Only for Pulse, MDB)
   EUR 50 display BGN 100 (Only for Pulse, MDB)
   EUR 100 display BGN 200 (Only for Pulse, MDB)
   EUR 200 display BGN 400 (Only for Pulse)

(1)

DIP Switch

This dip switch is located on the CPU board, remove the CPU board cover first.