

A7/V7 Option Switch Settings:1(Pulse/ccTalk)

Supported bill KWD ¼, ½, 1, 5 4bills.

A7/V7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject KWD ¼	ON											
	Accept KWD ¼	OFF											
★	Reject KWD ½		ON										
	Accept KWD ½		OFF										
★	Reject KWD 1			ON									
	Accept KWD 1			OFF									
★	Reject KWD 5				ON								
	Accept KWD 5				OFF								
★	Reserved					ON							
	Reserved					OFF							
★	Reserved						ON						
	Reserved						OFF						
★	Harness Disable							ON					
	Harness Enable							OFF					
★	Inhibit Active High								ON				
	Inhibit Active Low								OFF				
★	1 pulse / KWD 0.25									OFF	OFF		
	2 pulse / KWD 0.25									ON	OFF		
	4 pulse / KWD 0.25									OFF	ON		
	20 pulse / KWD 0.25									ON	ON		
★	Pulse Speed	50ms on / 50ms off										OFF	OFF
		60ms on / 300ms off										ON	OFF
		30ms on / 50ms off										OFF	ON
		100ms on / 100ms off										ON	ON

◆ Factory configuration has all switches in the OFF position.

Note : (1) Reset the bill acceptor after setting the dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	ccTalk Interface		OFF		
★	Reserved			ON	
				OFF	
★					ON
					OFF

Interface Settings: 3(ccTalk)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON		
★	ccTalk Interface		OFF		
▲	cctalk Parameters Restore Switch			ON	
				OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

▲ Put this switch to on and reset power will restore the cctalk address to its default value of 40, and the encryption key to its default value of 123456. This needs to be done after each White card Calibration.