

P70-HUF6

P70/P5 DIP SWITCHES SETTING : 1(Pulse/ccTalk)

Supported bill Ft 500, 1000, 2000, 5000, 10000, 20000 6 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / Ft 500	OFF	OFF	OFF							
	2 Pulse / Ft 500	OFF	OFF	ON							
	3 Pulse / Ft 500	OFF	ON	OFF							
	4 Pulse / Ft 500	OFF	ON	ON							
	5 Pulse / Ft 500	ON	OFF	OFF							
	10 Pulse / Ft 500	ON	OFF	ON							
	20 Pulse / Ft 500	ON	ON	OFF							
	100 Pulse / Ft 500	ON	ON	ON							
★	Fast output Pulse Lo= 75ms Hi = 75ms				ON						
	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept Ft 500					ON					
	Reject Ft 500					OFF					
★	Accept Ft 1000					ON					
	Reject Ft 1000					OFF					
★	Accept Ft 2000					ON					
	Reject Ft 2000					OFF					
★	Accept Ft 5000					ON					
	Reject Ft 5000					OFF					
★	Accept Ft 10000 & 20000					ON					
	Reject Ft 10000 & 20000					OFF					

★ Manufacture setting

Note: (1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

P70-HUF6/P5(Pulse/ccTalk)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Protocol		ON		
	ccTalk Protocol		OFF		
	Harness Disable			ON	
★	Harness Enable			OFF	
	Reserved				ON
★	Reserved				OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 & 3 are only used for pulse protocol.

Currency Assign Data

Interface Bill value	Pulse	ccTalk
BV1	Ft 500	Ft 500
BV2	Ft 500	Ft 500
BV3	Ft 500	Ft 500
BV4	Ft 500	Ft 500
BV5	Ft 1000	Ft 1000
BV6	Ft 2000	Ft 2000
BV7	Ft 5000	Ft 5000
BV8	Ft 10000	Ft 10000
BV9	Ft 10000	Ft 10000
BV10	Ft 20000	Ft 20000

DIP SWITCHES SETTING : 2(ccTalk)

	FUNCTION	SW1	SW2	SW3	SW4
★	Encryption Mode	ON			
	Decrypt Mode	OFF			
	Pulse Protocol		ON		
★	ccTalk Protocol		OFF		
	ccTalk Parameters Reset			ON	
★	Keep ccTalk Parameters			OFF	
	Reserved				ON
★	Reserved				OFF

(★) Manufacture setting

Note:(1) ccTalk Parameters Reset

Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

*This has to be done after finished calibration process.