

# RUB5

## P70/P2/P5 DIP SWITCHES SETTING : 1(Pulse/ccTalk)

Supported bill Ruble 10, 50, 100, 500, 1000 5bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / Ruble 10	OFF	OFF	OFF							
2 Pulses / Ruble 10	OFF	OFF	ON							
3 Pulses / Ruble 10	OFF	ON	OFF							
4 Pulses / Ruble 10	OFF	ON	ON							
5 Pulses / Ruble 10	ON	OFF	OFF							
10 Pulses / Ruble 10	ON	OFF	ON							
20 Pulses / Ruble 10	ON	ON	OFF							
100 Pulses / Ruble 10	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms				ON						
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept Ruble 10						ON				
Reject Ruble 10						OFF				
★ Accept Ruble 50							ON			
Reject Ruble 50							OFF			
★ Accept Ruble 100								ON		
Reject Ruble 100								OFF		
★ Accept Ruble 500									ON	
Reject Ruble 500									OFF	
★ Accept Ruble 1000										ON
Reject Ruble 1000										OFF

(★) Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

# P70-RUB5/P2/P5(Pulse/ccTalk)

## DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Protocol		ON		
ccTalk Protocol		OFF		
Harness Disable			ON	
★ Harness Enable			OFF	
Manufacture Default				ON
★ System Default				OFF

(★) Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 & 3 are only used for pulse protocol.

## Currency Assign Data

Interface Bill value	ccTalk	Pulse
BV1	Ruble 10	Ruble 10
BV2	Ruble 50	Ruble 50
BV3	Ruble 100	Ruble 100
BV4	Ruble 500	Ruble 500
BV5	Ruble N500	Ruble N500
BV6	Ruble 1000	Ruble 1000
BV7	Ruble N1000	Ruble N1000

## DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ Encryption Mode	ON			
Decrypt Mode	OFF			
Pulse Protocol		ON		
★ ccTalk Protocol		OFF		
ccTalk Parameters Reset			ON	
★ Keep ccTalk Parameters			OFF	
Manufacture Default				ON
★ System Default				OFF

(★) Manufacture setting

Note:(1) ccTalk Parameters Reset

Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

\*This has to be done after finished calibration process.