

## V77E-TRY6

### V77E Option Switch Settings : 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill TRY 5, 10, 20, 50, 100, 200 6bills.

V77E dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject TRY 5	ON											
★ Accept TRY 5	OFF											
★ Reject TRY 10		ON										
★ Accept TRY 10		OFF										
★ Reject TRY 20			ON									
★ Accept TRY 20			OFF									
★ Reject TRY 50				ON								
★ Accept TRY 50				OFF								
★ Reject TRY 100 & 200					ON							
★ Accept TRY 100 & 200					OFF							
★ Reserved					ON							
★ Reserved					OFF							
★ <b>Pulse Mode</b>	<b>Other Mode</b>											
★ Harness Disable	BA stops working when fishing				ON							
★ Harness Enable	Normal				OFF							
★ Inhibit Active High							ON					
★ Inhibit Active Low							OFF					
★ 1 pulse / TRY 5								OFF	OFF			
★ 5 pulses / TRY 5								ON	OFF			
★ 10 pulses / TRY 5								OFF	ON			
★ 25 pulses / TRY 5								ON	ON			
★ Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
	60ms LO / 300ms HI								ON	OFF		
	30ms LO / 50ms HI								OFF	ON		
	150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

## V77E-TRY6(Pulse/ICT104V/ICT104U/MDB)

### Interface Settings: 2(Pulse) Currency Assign Data

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Interface		ON	OFF	
ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting

Interface Bill value	ICT104U	ICT104V	Pulse	MDB
BV1	TRY 5	TRY 5	TRY 5	TRY 5
BV2	TRY 10	TRY 10	TRY 10	TRY 10
BV3	TRY 20	TRY 20	TRY 20	TRY 20
BV4	TRY 50	TRY 50	TRY 50	TRY 50
BV5	TRY 100	TRY 100	TRY 100	TRY 100
BV6	TRY 200	TRY 200	TRY 200	TRY 200

### Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Interface		ON	OFF	
★ ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting

### Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Interface		ON	OFF	
ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
★ ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting

### Interface Settings: 2(MDB)

INTERFACE	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Interface		ON	OFF	
★ ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting