

V7E/LX7-UAH6

V7E/LX7 Option Switch Settings: 1(Pulse/ICT/MDB)

Supported bill UAH 1, 2, 5, 10, 20, 50 6bills.

V7E/LX7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject UAH 1 & 2	ON											
★ Accept UAH 1 & 2	OFF											
★ Reject UAH 5		ON										
★ Accept UAH 5		OFF										
★ Reject UAH 10			ON									
★ Accept UAH 10			OFF									
★ Reject UAH 20				ON								
★ Accept UAH 20				OFF								
★ Reject UAH 50					ON							
★ Accept UAH 50					OFF							
★ Reserved						ON						
★ Reserved						OFF						
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / UAH 1									OFF	OFF		
★ 5 pulses / UAH 1									ON	OFF		
★ 10 pulses / UAH 1									OFF	ON		
★ 20 pulses / UAH 1									ON	ON		
★ Pulse Speed	50ms on / 50ms off										OFF	OFF
	60ms on / 300ms off										ON	OFF
	30ms on / 50ms off										OFF	ON
	150ms on / 150ms off										ON	ON

★ Manufacture setting

Note : (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

V7E/LX7-UAH6(Pulse/ICT/MDB)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
MDB Interface		ON	ON	
Reserved		OFF	OFF	
★ Reserved				ON
				OFF

Currency Assign Data

Interface Bill value	ICT	Pulse	MDB
BV1	UAH 1	UAH 1	UAH 1
BV2	UAH 2	UAH 2	UAH 2
BV3	UAH 5	UAH 5	UAH 5
BV4	UAH 10	UAH 10	UAH 10
BV5	UAH 20	UAH 20	UAH 20
BV6	UAH 50	UAH 50	UAH 50

DIP SWITCHES SETTING : 2(ICT)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
MDB Interface		ON	ON	
Reserved		OFF	OFF	
★ Reserved				ON
				OFF

DIP SWITCHES SETTING : 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	OFF			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0				
Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
MDB Interface		ON	ON	
Reserved		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.(Please refer to "Sw1" setting.)