

## V7E/LX7-BND4

### V7E/LX7 Option Switch Settings: 1(Pulse/ICT104V/MDB/ICT104U)

**Supported bill BND 1, 5, 10, 20 4bills.**

V7E/LX7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject BND 1	ON											
★ Accept BND 1	OFF											
★ Reject BND 5		ON										
★ Accept BND 5		OFF										
★ Reject BND 10			ON									
★ Accept BND 10			OFF									
★ Reject BND 20				ON								
★ Accept BND 20				OFF								
★ Reserved					ON							
★ Reserved					OFF							
★ Reserved						ON						
★ Reserved						OFF						
★ <b>Pulse Mode</b>	<b>Other Mode</b>											
★ Harness Disable	BA stops working when fishing						ON					
★ Harness Enable	Normal						OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / BND 1									OFF	OFF		
★ 5 pulses / BND 1									ON	OFF		
★ 10 pulses / BND 1									OFF	ON		
★ 20 pulses / BND 1									ON	ON		
★ Pulse Speed	50ms LO / 50ms HI										OFF	OFF
	60ms LO / 300ms HI										ON	OFF
	30ms LO / 50ms HI										OFF	ON
	150ms LO / 150ms HI										ON	ON

★ Manufacture setting

Note : (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

## V7E/LX7-BND4(Pulse/ICT104V/MDB/ICT104U)

### DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ICT104U Interface		OFF	ON	
ICT104V Interface		ON	ON	
MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

### Currency Assign Data

Interface Bill value	ICT	Pulse	MDB
BV1	BND 1	BND 1	BND 1
BV2	BND 5	BND 5	BND 5
BV3	BND 10	BND 10	BND 10
BV4	BND 20	BND 20	BND 20

### DIP SWITCHES SETTING : 2(ICT104V)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
ICT104U Interface		OFF	ON	
★ ICT104V Interface		ON	ON	
MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

### DIP SWITCHES SETTING : 2(ICT104U)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
ICT104V Interface		ON	ON	
MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

### DIP SWITCHES SETTING : 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
ICT104U Interface		OFF	ON	
ICT104V Interface		ON	ON	
★ MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.(Please refer to "Sw1" setting.)