

## V7E/LX7-ZAR4

### V7E/LX7 Option Switch Settings: 1(Pulse/ICT/MDB)

Supported bill R 10, 20, 50, 100

4bills.

V7E/LX7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject R 10	ON											
★ Accept R 10	OFF											
★ Reject R 20		ON										
★ Accept R 20		OFF										
★ Reject R 50			ON									
★ Accept R 50			OFF									
★ Reject R 100				ON								
★ Accept R 100				OFF								
★ Reserved				ON								
★ Reserved				OFF								
★ Reserved					ON							
★ Reserved					OFF							
★ Harness Disable						ON						
★ Harness Enable						OFF						
★ Inhibit Active High							ON					
★ Inhibit Active Low							OFF					
★ 1 pulse / R 10								OFF	OFF			
5 pulses / R 10								ON	OFF			
10 pulses / R 10								OFF	ON			
20 pulses / R 10								ON	ON			
★ Pulse Speed	50ms on / 50ms off									OFF	OFF	
	60ms on / 300ms off									ON	OFF	
	30ms on / 50ms off									OFF	ON	
	150ms on / 150ms off									ON	ON	

★ Manufacture setting

Note : (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

## V7E/LX7-ZAR4(Pulse/ICT/MDB)

### DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ICT Interface		OFF	ON	
MDB Interface		ON	ON	
Reserved		OFF	OFF	
★ Reserved				ON
				OFF

### Currency Assign Data

Interface Bill value	ICT	Pulse	MDB
BV1	R 10	R 10	R 10
BV2	R 20	R 20	R 20
BV3	R 50	R 50	R 50
BV4	R 100	R 100	R 100

### DIP SWITCHES SETTING : 2(ICT)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
MDB Interface		ON	ON	
Reserved		OFF	OFF	
★ Reserved				ON
				OFF

### DIP SWITCHES SETTING : 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
MDB Interface		ON	ON	
Reserved		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.