

V7E/LX7-ZAR5

V7E/LX7 Option Switch Settings: 1(Pulse/ICT002U/M.D.B)

Supported bill R 10, 20, 50, 100, 200 5bills.

V7E/LX7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject R 10	ON											
★	Accept R 10	OFF											
★	Reject R 20		ON										
★	Accept R 20		OFF										
★	Reject R 50			ON									
★	Accept R 50			OFF									
★	Reject R 100				ON								
★	Accept R 100				OFF								
★	Reject R 200					ON							
★	Accept R 200					OFF							
★	Reserved					ON							
★	Reserved					OFF							
★	Harness Disable						ON						
★	Harness Enable						OFF						
★	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / R 10								OFF	OFF			
★	5 pulse / R 10								ON	OFF			
★	10 pulse / R 10								OFF	ON			
★	20 pulse / R 10								ON	ON			
★	Pulse Speed	50ms LO / 50ms HI									OFF	OFF	
		60ms LO / 300ms HI									ON	OFF	
		30ms LO / 50ms HI									OFF	ON	
		150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

◆ Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

V7E/LX7-ZAR5(Pulse/ICT002U/M.D.B)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ICT002U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

DIP SWITCHES SETTING : 2(ICT002U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ICT002U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

Currency Assign Data

Interface Bill value	Pulse	MDB	ICT002U
BV1	ZAR 10	ZAR 10	ZAR 10
BV2	ZAR 20	ZAR 20	ZAR 20
BV3	ZAR 50	ZAR 50	ZAR 50
BV4	ZAR 100	ZAR 100	ZAR 100
BV5	ZAR 200	ZAR 200	ZAR 200

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT002U Interface		OFF	ON	
★	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.