BR2300-SAR4

BR2300 DIP SWITCHES SETTING: (MDB/ICT-BC/ccTalk) Supported bill SAR 1, 5, 10, 50 4bills.

	FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	FUNCTION			SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	Reject SAR 1		ON									
*	Accept SAR 1		OFF									
	Reject SAR 5 & 10			ON								
*	Accept SAR 5 & 10			OFF								
	Reject SAR 50				ON							
×	Accept SAR 50				OFF							
	High Acceptance	(Note.3)				ON						
×	High Security					OFF						
×	Scaling Factor (SF) = 1 Decimal Point Position (DP	00 P) = 2	(MDB On	ly)			ON					
	Scaling Factor (SF) = 1 Decimal Point Position (DPF	1					OFF					
×	Normal							OFF	OFF			
	Load Banknote to Recycle	;						ON	OFF			
	Load Banknote to Stacker						OFF	ON				
	Unload Banknote to Stacker						ON	ON				
×	ccTalk									ON	OFF	
	ccTalk	(Note.1)								OFF	ON	
*	MDB Mode		OFI				OFF	OFF				
×	ICT-BC Mode		ON Of				ON					
	ccTalk		MDE	Mode				ICT-	BC Mo	de		
×	Encryption MODE V	/irtual MD	B Recy	cler Fun	ction (N	ote.2)				ON		
	Decrypt MODE	Standar	d MDB	Recycle	r Functi	on	Conne	ct with	RS232	2 Conn	ector	OFF

★ Manufacture setting

reset the bill acceptor again.

Note.1: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

Note.2 Recycked Banknote represents virtual MDB

Note.3: High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.4: calibrate card.

After setting dip switch of the credit pulses, you should **Currency Assign Data**

Interface Bill value	ccTalk	ICT-BC	MDB
BV1	SAR 1	SAR 1	SAR 1
BV2	SAR 5	SAR 5	SAR 5
BV3	SAR 10	SAR 10	SAR 10
BV4			
BV5	SAR 50	SAR 50	SAR 50

Appendix

© 2017 International Currency Technologies Corporation V. 2.0 Part Number: SWBNSA420-R