

DOP7

L83 DIP SWITCHES SETTING : 1(Pulse/ccTalk/Smiley Parallel Compatible)

**Supported bill RD\$ 10, 20, 50, 100, 200, 500, 1000
7 bills.**

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / RD\$ 10	OFF	OFF	OFF							
	2 Pulse / RD\$ 10	OFF	OFF	ON							
	3 Pulse / RD\$ 10	OFF	ON	OFF							
	4 Pulse / RD\$ 10	OFF	ON	ON							
	5 Pulse / RD\$ 10	ON	OFF	OFF							
	10 Pulse / RD\$ 10	ON	OFF	ON							
	20 Pulse / RD\$ 10	ON	ON	OFF							
	100 Pulse / RD\$ 10	ON	ON	ON							
	Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★	Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept RD\$ 10 & 20				ON						
	Reject RD\$ 10 & 20				OFF						
★	Accept RD\$ 50 & 100				ON						
	Reject RD\$ 50 & 100				OFF						
★	Accept RD\$ 200				ON						
	Reject RD\$ 200				OFF						
★	Accept RD\$ 500				ON						
	Reject RD\$ 500				OFF						
★	Accept RD\$ 1000				ON						
	Reject RD\$ 1000				OFF						

★ Manufacture setting

Note:(1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

L83-DOP7(Pulse/ccTalk/Smiley Parallel Compatible)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(ccTalk)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	ccTalk Interface		OFF	OFF	
	ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

Note: Put this switch to on and reset power will restore the CCTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING : 2(Smiley Parallel Compatible)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	Smiley Parallel Compatible Mode		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting