

## V7E/LX7-TZS5

### V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/M.D.B)

Supported bill TZS 500, 1000, 2000, 5000, 10000 5bills.

V7E dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject TZS 500	ON											
	Accept TZS 500	OFF											
	Reject TZS 1000		ON										
★	Accept TZS 1000		OFF										
	Reject TZS 2000			ON									
★	Accept TZS 2000			OFF									
	Reject TZS 5000				ON								
★	Accept TZS 5000				OFF								
	Reject TZS 10000					ON							
★	Accept TZS 10000					OFF							
	Reserved					ON							
★	Reserved					OFF							
	<b>Pulse Mode</b>	<b>Other Mode</b>											
	Harness Disable	BA stops working when fishing						ON					
★	Harness Enable	Normal						OFF					
	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / TZS 500								OFF	OFF			
	2 pulse / TZS 500								ON	OFF			
	4 pulse / TZS 500								OFF	ON			
	20 pulse / TZS 500								ON	ON			
★	Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

◆ Note : 1.Reset the bill acceptor after setting the dip switch

2.SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

3.Use both 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

## V7E/LX7-TZS5(Pulse/ICT104U/M.D.B)

### DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

### DIP SWITCHES SETTING : 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

### Currency Assign Data

Interface Bill value	Pulse	MDB	ICT104U
BV1	TZS 500	TZS 500	TZS 500
BV2	TZS 1000	TZS 1000	TZS 1000
BV3	TZS 2000	TZS 2000	TZS 2000
BV4	TZS 5000	TZS 5000	TZS 5000
BV5	TZS 10000	TZS 10000	TZS 10000

### DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT Interface		OFF	ON	
★	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.