

A7/V7-GBP2

A7/V7 Option Switch Settings : 1

Supported bill

England banknotes : Bank of England £ 5, £ 10

Scotland banknotes: Bank of Scotland £ 5, £ 10

Royal Bank of Scotland £ 5, £ 10

V7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject GBP 5	ON											
	Accept GBP 5	OFF											
	Reject GBP 10		ON										
★	Accept GBP 10		OFF										
	Reserved			ON									
★	Reserved			OFF									
	Reserved				ON								
★	Reserved			OFF									
	Reserved				ON								
★	Reserved				OFF								
	Reserved				ON								
★	Reserved				OFF								
	Reserved				ON								
★	Reserved				OFF								
	Harness Disable						ON						
★	Harness Enable						OFF						
	Inhibit Active High						ON						
★	Inhibit Active Low						OFF						
★	1 pulse / GBP 5								OFF	OFF			
	5 pulses / GBP 5								ON	OFF			
	10 pulses / GBP 5								OFF	ON			
	20 pulses / GBP 5								ON	ON			
★	Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note: (1) Default setting.

A7/V7-GBP2 (PULSE/MDB)

V7 Interface Settings: 3 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	MDB Interface		OFF		
	Reserved			ON	
★	Reserved			OFF	
	Reserved				ON
★	Reserved				OFF

★ Manufacture setting

V7 Interface Settings: 3 (MDB)

	INTERFACE	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	MDB Interface		OFF		
	Reserved			ON	
★	Reserved			OFF	
	Reserved				ON
★	Reserved				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse	MDB
BV1	GBP 5	GBP 5
BV2	GBP 10	GBP 10