

## BR2300-FJD6

### BR2300 DIP SWITCHES SETTING : (MDB/ICT-BC/ccTalk)

Supported bill FJD 5, 7, 10, 20, 50, 100 6bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	Reject FJD 5 & 7	ON									
★	Accept FJD 5 & 7	OFF									
	Reject FJD 10 & 20		ON								
★	Accept FJD 10 & 20		OFF								
	Reject FJD 50 & 100			ON							
★	Accept FJD 50 & 100			OFF							
	High Acceptance <small>(Note.3)</small>				ON						
★	High Security				OFF						
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2 <small>(MDB Only)</small>					ON					
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0					OFF					
★	Normal						OFF	OFF			
	Load Banknote to Recycle						ON	OFF			
	Load Banknote to Stacker						OFF	ON			
	Unload Banknote to Stacker						ON	ON			
★	ccTalk								ON	OFF	
	ccTalk <small>(Note.1)</small>								OFF	ON	
★	MDB Mode								OFF	OFF	
★	ICT-BC Mode								ON	ON	
	ccTalk	MDB Mode			ICT-BC Mode						
★	Encryption MODE	★ Virtual MDB Recycler Function (Note.2)			Connect with MDB Connector						ON
	Decrypt MODE	Standard MDB Recycler Function			★ Connect with RS232 Connector						OFF

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note. 1: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

Note.2 Recycled Banknote represents virtual MDB coin type.

Note.3: High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.4: Calibration card is needed.

## BR2300-FJD6(MDB/ICT-BC/ccTalk)

### Currency Assign Data

Interface Bill value	ccTalk	ICT-BC	MDB	Recycler banknote inventory
BV1	FJD 5	FJD 5	FJD 5	FJD 5 45 pcs
BV2	FJD 7	FJD 7	FJD 7	FJD 7 40 pcs
BV3	FJD 10	FJD 10	FJD 10	FJD 10 40 pcs
BV4	FJD 20	FJD 20	FJD 20	FJD 20 40 pcs
BV5	FJD 50	FJD 50	FJD 50	FJD 50 40 pcs
BV6	FJD 100	FJD 100	FJD 100	FJD 100 40 pcs