

BRV-HUF6

BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy)

Supported bill HUF 500, 1000, 2000, 5000, 10000, 20000 6bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject HUF 500 & 1000	ON											
★ Accept HUF 500 & 1000	OFF											
★ Reject HUF 2000		ON										
★ Accept HUF 2000		OFF										
★ Reject HUF 5000			ON									
★ Accept HUF 5000			OFF									
★ Reject HUF 10000				ON								
★ Accept HUF 10000				OFF								
★ Reject HUF 20000					ON							
★ Accept HUF 20000					OFF							
★ Normal					OFF	OFF						
Load Banknote to Recycle					ON	OFF						
Load Banknote to Stacker					OFF	ON						
Unload Banknote to cash out					ON	ON						
★ Reserved								ON				
★ Reserved								OFF				
MDB Mode	SW1	SW2	SW3	SW4	JPSTD Dummy Mode							
★ Reserved	ON				★ 255 Bank Note Limitation Per Transaction	ON	ON	ON				
★ Reserved	OFF				1 Bank Note Limitation Per Transaction	OFF	OFF	OFF				
★ Reserved		ON			2 Bank Note Limitation Per Transaction	ON	OFF	OFF				
★ Reserved		OFF			3 Bank Note Limitation Per Transaction	OFF	ON	OFF				
★ Reserved					4 Bank Note Limitation Per Transaction	ON	ON	OFF				
★ Reserved				ON	5 Bank Note Limitation Per Transaction	OFF	OFF	ON				
★ Reserved				OFF	6 Bank Note Limitation Per Transaction	ON	OFF	ON				
★ Virtual MDB Recycler Function (Note.4)				ON	No Refund After the Deal							ON
★ Standard MDB Recycler Function				OFF	★ Refund After the Deal							OFF

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

(2) Please reset the bill acceptor after set the dip switch.

(3) Calibration card is needed

(4) Recycled Banknote represents virtual MDB coin type.

(5)The credit divide by 10 on JPSTD Dummy Mode.

BRV-HUF6(ICT-BC/MDB/JPSTD Dummy)

Interface Settings: 2(ICT-BC)

Interface Settings: 2(JPSTD Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
Connect with MDB Connector		ON		
★ Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

INTERFACE	SW5	SW6	SW7	SW8
Escrow (JPSTD Dummy Mode)	ON			
★ No Escrow (JPSTD Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ JPSTD Dummy Mode	(Note.5)		OFF	ON
Reserved			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Scaling Factor (SF)= 100				
Decimal Point Position (DPP) = 2	ON			
★ Scaling Factor (SF)= 1				
Decimal Point Position (DPP) = 0	OFF			
Reserved		ON		
★ Reserved		OFF		
★ MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD Dummy	ICT-BC	MDB	Recycler banknote inventory	
	BV1	HUF 500	HUF 500	HUF 500	HUF 500
BV2	HUF 1000	HUF 1000	HUF 1000	HUF 1000	30 pcs
BV3	HUF 2000	HUF 2000	HUF 2000	HUF 2000	30 pcs
BV4	HUF 5000	HUF 5000	HUF 5000	HUF 5000	30 pcs
BV5	HUF 10000	HUF 10000	HUF 10000	HUF 10000	30 pcs
BV6	HUF 20000	HUF 20000	HUF 20000	HUF 20000	30 pcs