

BRV-KRW4

BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy)

Supported bill KRW 1000, 5000, 10000, 50000 4bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject KRW 1000	ON											
★ Accept KRW 1000	OFF											
Reject KRW 5000		ON										
★ Accept KRW 5000		OFF										
Reject KRW 10000			ON									
★ Accept KRW 10000			OFF									
Reject KRW 50000				ON								
★ Accept KRW 50000				OFF								
Reserved					ON							
★ Reserved					OFF							
★ Normal						OFF	OFF					
Load Banknote to Recycle						ON	OFF					
Load Banknote to Stacker						OFF	ON					
Unload Banknote to Stacker						ON	ON					
Reserved								ON				
★ Reserved								OFF				
MDB Mode	SW1	SW2	SW3	SW4	JPSTD Dummy Mode							
Reserved	ON				★ 255 Bank Note Limitation Per Transaction	ON	ON	ON				
★ Reserved	OFF				1 Bank Note Limitation Per Transaction	OFF	OFF	OFF				
Reserved		ON			2 Bank Note Limitation Per Transaction	ON	OFF	OFF				
★ Reserved		OFF			3 Bank Note Limitation Per Transaction	OFF	ON	OFF				
Reserved			ON		4 Bank Note Limitation Per Transaction	ON	ON	OFF				
★ Reserved			OFF		5 Bank Note Limitation Per Transaction	OFF	OFF	ON				
Reserved				ON	6 Bank Note Limitation Per Transaction	ON	OFF	ON				
★ Reserved				OFF	7 Bank Note Limitation Per Transaction	OFF	ON	ON				
Virtual MDB Recycler Function	(Note.4)			ON	No Refund After the Deal							ON
★ Standard MDB Recycler Function				OFF	★ Refund After the Deal							OFF

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses ,you should reset the bill acceptor again.

(2) Please reset the bill acceptor after set the dip switch.

(3) Calibration card is needed.

(4) Recycled Banknote represents virtual MDB coin type.

BRV-KRW4(ICT-BC/MDB/JPSTD Dummy)

Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
Connect with MDB Connector		ON		
★ Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(JPSTD Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Escrow (JPSTD Dummy Mode)	ON			
★ No Escrow (JPSTD Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Scaling Factor (SF)= 100 Decimal Point Position (DPP)= 2	ON			
Scaling Factor (SF)= 1 Decimal Point Position (DPP)= 0	OFF			
Reserved		ON		
★ Reserved		OFF		
★ MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD Dummy	ICT-BC	MDB	Recycler banknote inventory	
	BV1	KRW 1000	KRW 1000	KRW 1000	KRW 1000
BV2	KRW 5000	KRW 5000	KRW 5000	KRW 5000	35 pcs
BV3	KRW 10000	KRW 10000	KRW 10000	KRW 10000	30 pcs
BV4	KRW 50000	KRW 50000	KRW 50000	KRW 50000	30 pcs