

BRV-LAK8

BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

Supported bill LAK 500, 1000, 2000, 5000, 10000, 20000, 50000, 100000 8bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject LAK 500 & 1000	ON											
★ Accept LAK 500 & 1000	OFF											
★ Reject LAK 2000 & 5000		ON										
★ Accept LAK 2000 & 5000		OFF										
★ Reject LAK 10000 & 20000			ON									
★ Accept LAK 10000 & 20000			OFF									
★ Reject LAK 50000				ON								
★ Accept LAK 50000				OFF								
★ Reject LAK 100000					ON							
★ Accept LAK 100000					OFF							
★ Normal						OFF	OFF					
★ Load Banknote to Recycle						ON	OFF					
★ Load Banknote to Stacker						OFF	ON					
★ Unload Banknote to Stacker						ON	ON					
★ Reserved								ON				
★ Reserved								OFF				
MDB Mode	MDB Dummy Mode		SW1	SW2	SW3	SW4	JPSTD Dummy Mode					
★ Reserved	Reserved	Reserved	ON				★ 255 Bank Note Limitation Per Transaction	ON	ON	ON		
★ Reserved	Reserved	Reserved	OFF				1 Bank Note Limitation Per Transaction	OFF	OFF	OFF		
★ Reserved	Reserved	Reserved		ON			2 Bank Note Limitation Per Transaction	ON	OFF	OFF		
★ Reserved	Reserved	Reserved		OFF			3 Bank Note Limitation Per Transaction	OFF	ON	OFF		
★ Reserved	Reserved	Reserved			ON		4 Bank Note Limitation Per Transaction	ON	ON	OFF		
★ Reserved	Reserved	Reserved				ON	5 Bank Note Limitation Per Transaction	OFF	OFF	ON		
★ Reserved	Reserved	Reserved				OFF	6 Bank Note Limitation Per Transaction	ON	OFF	ON		
★ Virtual MDB Recycler Function (Note.4)	No Refund After the Deal					ON	No Refund After the Deal					ON
★ Standard MDB Recycler Function	★ Refund After the Deal					OFF	★ Refund After the Deal					OFF

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

- (2) Please reset the bill acceptor after set the dip switch.
- (3) Calibrate card is needed.
- (4) Recycled Banknote represents virtual MDB coin type.
- (5) Normal:Scaling Factor (SF) = 1
Decimal Point Position (DPP) = 0

BRV-LAK8(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
★ Connect with MDB Connector		ON		
★ Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(JPSTD Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Escrow (JPSTD Dummy Mode)	ON			
★ No Escrow (JPSTD Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Scaling Factor (SF)= 1 Decimal Point Position (DPP)= 0	OFF	OFF		
Scaling Factor (SF)= 100 Decimal Point Position (DPP)= 2	OFF	ON		
Credit divide by 100	ON	OFF		
Reserved	ON	ON		
★ MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB Dummy)

INTERFACE	SW5	SW6	SW7	SW8
★ Reserved	OFF	OFF		
Reserved	OFF	ON		
Credit divide by 100	ON	OFF		
Reserved	ON	ON		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
★ MDB Dummy Mode (Note.5)			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD Dummy	ICT-BC	MDB MDB Dummy	Recycler banknote inventory	
BV1		LAK 500	LAK 500	LAK 500	30 pcs
BV2	LAK 1000	LAK 1000	LAK 1000	LAK 1000	30 pcs
BV3	LAK 2000	LAK 2000	LAK 2000	LAK 2000	30 pcs
BV4	LAK 5000	LAK 5000	LAK 5000	LAK 5000	30 pcs
BV5	LAK 10000	LAK 10000	LAK 10000	LAK 10000	30 pcs
BV6	LAK 20000	LAK 20000	LAK 20000	LAK 20000	30 pcs
BV7	LAK 50000	LAK 50000	LAK 50000	LAK 50000	30 pcs
BV8	LAK100000	LAK100000	LAK100000	LAK100000	30 pcs