

# BRV-MDL6

## BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

Supported bill MDL 10, 20, 50, 100, 200, 500 6bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject MDL 10 & 20	ON											
★ Accept MDL 10 & 20	OFF											
★ Reject MDL 50		ON										
★ Accept MDL 50		OFF										
★ Reject MDL 100			ON									
★ Accept MDL 100			OFF									
★ Reject MDL 200				ON								
★ Accept MDL 200				OFF								
★ Reject MDL 500					ON							
★ Accept MDL 500					OFF							
★ Normal						OFF	OFF					
Load Banknote to Recycle						ON	OFF					
Load Banknote to Stacker						OFF	ON					
Unload Banknote to Stacker						ON	ON					
Reserved								ON				
★ Reserved								OFF				
<b>MDB Mode</b>	<b>MDB Dummy Mode</b>	SW1	SW2	SW3	SW4	<b>JPSTD Dummy Mode</b>						
Reserved	Reserved	ON				★ 255 Bank Note Limitation Per Transaction	ON	ON	ON			
★ Reserved	Reserved	OFF				1 Bank Note Limitation Per Transaction	OFF	OFF	OFF			
Reserved	Reserved		ON			2 Bank Note Limitation Per Transaction	ON	OFF	OFF			
★ Reserved	Reserved		OFF			3 Bank Note Limitation Per Transaction	OFF	ON	OFF			
Reserved	Reserved			ON		4 Bank Note Limitation Per Transaction	ON	ON	OFF			
★ Reserved	Reserved			OFF		5 Bank Note Limitation Per Transaction	OFF	OFF	ON			
Reserved	Reserved				ON	6 Bank Note Limitation Per Transaction	ON	OFF	ON			
★ Reserved	Reserved				OFF	7 Bank Note Limitation Per Transaction	OFF	ON	ON			
Virtual MDB (Note.4) Recycler Function	No Refund After the Deal				ON	No Refund After the Deal						ON
★ Standard MDB Recycler Function	★ Refund After the Deal				OFF	★ Refund After the Deal						OFF

★ Manufacture setting

- Note : (1) After setting dip switch of the credit pulses, you should reset the bill acceptor again.  
 (2) Please reset the bill acceptor after set the dip switch.  
 (3) Calibration card is needed.  
 (4) Recycled Banknote represents virtual MDB coin type.  
 (5) Virtual Coin Changer : Scaling Factor = 1, Decimal Point Position = 1.

# BRV-MDL6(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

## Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
Connect with MDB Connector		ON		
★ Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

## Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Scaling Factor (SF)= 100 Decimal Point Position (DPP)= 2	ON			
Scaling Factor (SF)= 1 Decimal Point Position (DPP)= 0	OFF			
Reserved		ON		
★ Reserved		OFF		
★ MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

## Interface Settings: 2(JPSTD Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Escrow (JPSTD Dummy Mode)	ON			
★ No Escrow (JPSTD Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

## Interface Settings: 2(MDB Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
★ MDB Dummy Mode	(Note.5)		ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

# Currency Assign Data

Interface Bill value	JPSTD Dummy	ICT-BC	MDB (Dummy)	Recycler banknote inventory	
	BV1	MDL 10	MDL 10	MDL 10	MDL 10
BV2	MDL 20	MDL 20	MDL 20	MDL 20	40 pcs
BV3	MDL 50	MDL 50	MDL 50	MDL 50	40 pcs
BV4	MDL 100	MDL 100	MDL 100	MDL 100	35 pcs
BV5	MDL 200	MDL 200	MDL 200	MDL 200	35 pcs
BV6	MDL 500	MDL 500	MDL 500	MDL 500	35 pcs