

L83-CZK6

L83 DIP SWITCHES SETTING : 1

Supported bill Kč 100, 200, 500, 1000, 2000, 5000 6bills.
 With stacker : Kč 100, 200, 500, 1000 4bills.

| FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| ★ 1 Pulse / Kč 50 | OFF | OFF | OFF | | | | | | | |
| 2 Pulse / Kč 50 | OFF | OFF | ON | | | | | | | |
| 3 Pulse / Kč 50 | OFF | ON | OFF | | | | | | | |
| 4 Pulse / Kč 50 | OFF | ON | ON | | | | | | | |
| 5 Pulse / Kč 50 | ON | OFF | OFF | | | | | | | |
| 10 Pulse / Kč 50 | ON | OFF | ON | | | | | | | |
| 20 Pulse / Kč 50 | ON | ON | OFF | | | | | | | |
| 100 Pulse / Kč 50 | ON | ON | ON | | | | | | | |
| Fast output Pulse <small>Lo= 50ms Hi=100ms</small> | | | | ON | | | | | | |
| ★ Slow output Pulse <small>Lo= 50ms Hi=300ms</small> | | | | OFF | | | | | | |
| Inhibit level Active Low | | | | | ON | | | | | |
| ★ Inhibit level Active High | | | | | OFF | | | | | |
| ★ Accept Kč 100 | | | | | | ON | | | | |
| Reject Kč 100 | | | | | | OFF | | | | |
| ★ Accept Kč 200 & 500 | | | | | | | ON | | | |
| Reject Kč 200 & 500 | | | | | | | OFF | | | |
| ★ Accept Kč 1000 | | | | | | | | ON | | |
| Reject Kč 1000 | | | | | | | | OFF | | |
| ★ Accept Kč 2000 | | | | | | | | | ON | |
| Reject Kč 2000 | | | | | | | | | OFF | |
| ★ Accept Kč 5000 | | | | | | | | | | ON |
| Reject Kč 5000 | | | | | | | | | | OFF |

★ Manufacture setting

Note:(1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

L83-CZK6(Pulse/ccTalk/Parallel A5)

DIP SWITCHES SETTING : 2(Pulse)

| FUNCTION | SW1 | SW2 | SW3 | SW4 |
|--|-----|-----|-----|-----|
| ★ Pulse Normal High | ON | | | |
| Pulse Normal Low | OFF | | | |
| ★ Pulse Mode | | ON | OFF | |
| ccTalk Interface | | OFF | OFF | |
| Parallel A5 Mode | | ON | ON | |
| ccTalk Parameters Restore Switch (Please see Note.3 for Detail) | | OFF | ON | |
| ★ Reserved | | | | ON |
| | | | | OFF |

★ Manufacture setting

DIP SWITCHES SETTING : 2(ccTalk)

| FUNCTION | SW1 | SW2 | SW3 | SW4 |
|--|-----|-----|-----|-----|
| ★ CRC 16-bit checksum | ON | | | |
| 8-bit checksum | OFF | | | |
| Pulse Mode | | ON | OFF | |
| ★ cctalk Interface | | OFF | OFF | |
| Parallel A5 Mode | | ON | ON | |
| ccTalk Parameters Restore Switch (Please see Note.3 for Detail) | | OFF | ON | |
| ★ Encryption Mode | | | | ON |
| Decrypt Mode | | | | OFF |

★ Manufacture setting

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING : 2(Parallel A5)

| FUNCTION | SW1 | SW2 | SW3 | SW4 |
|--|-----|-----|-----|-----|
| ★ Reserved | ON | | | |
| | OFF | | | |
| Pulse Mode | | ON | OFF | |
| cctalk Interface | | OFF | OFF | |
| Parallel A5 Mode | | ON | ON | |
| ccTalk Parameters Restore Switch (Please see Note.3 for Detail) | | OFF | ON | |
| ★ Reserved | | | | ON |
| | | | | OFF |

★ Manufacture setting

Currency Assign Data

| Interface Bill value | Pulse | ccTalk | Parallel A5 |
|-------------------------|---------|---------|-------------|
| BV1 | | | |
| BV2 | Kč 100 | Kč 100 | Kč 100 |
| BV3 | Kč 200 | Kč 200 | Kč 200 |
| BV4 | Kč 500 | Kč 500 | Kč 500 |
| BV5 | Kč 1000 | Kč 1000 | Kč 1000 |
| BV6 | Kč 2000 | Kč 2000 | Kč 2000 |
| BV7 | Kč 5000 | Kč 5000 | Kč 5000 |