

# L83-HRK5

## L83-P3/P6 DIP SWITCHES SETTING : 1(Pulse/ccTalk/Parallel A5)

Supported bill HRK 10, 20, 50, 100, 200 5bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / HRK 10	OFF	OFF	OFF							
2 Pulse / HRK 10	OFF	OFF	ON							
3 Pulse / HRK 10	OFF	ON	OFF							
4 Pulse / HRK 10	OFF	ON	ON							
5 Pulse / HRK 10	ON	OFF	OFF							
10 Pulse / HRK 10	ON	OFF	ON							
20 Pulse / HRK 10	ON	ON	OFF							
100 Pulse / HRK 10	ON	ON	ON							
Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★ Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept HRK 10						ON				
Reject HRK 10						OFF				
★ Accept HRK 20							ON			
Reject HRK 20							OFF			
★ Accept HRK 50								ON		
Reject HRK 50								OFF		
★ Accept HRK 100									ON	
Reject HRK 100									OFF	
★ Accept HRK 200										ON
Reject HRK 200										OFF

★ Manufacture setting

Note:(1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

# L83-HRK5(Pulse/ccTalk/Parallel A5)

## DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
Parallel A5 Mode		ON	ON	
Reserved				ON
				OFF

★ Manufacture setting

## DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ccTalk Interface		OFF	OFF	
ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
Parallel A5 Mode		ON	ON	
★ Encryption Mode				ON
Decrypt Mode				OFF

★ Manufacture setting

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

## DIP SWITCHES SETTING : 2(Parallel A5)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
★ Parallel A5 Mode		ON	ON	
Reserved				ON
				OFF

## Currency Assign Data

Interface Bill value	Pulse	ccTalk	Parallel A5
BV1	HRK 10	HRK 10	HRK 10
BV2	HRK 20	HRK 20	HRK 20
BV3	HRK 50	HRK 50	HRK 50
BV4	HRK 100	HRK 100	HRK 100
BV5	HRK 200	HRK 200	HRK 200