

L83-UZS8

L83 DIP SWITCHES SETTING : 1(Pulse/ICT104U)

Supported bill UZS 1000, 2000, 5000, 10000, 20000, 50000, 100000, 200000 8bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / UZS 1000	OFF	OFF	OFF							
2 Pulses / UZS 1000	OFF	OFF	ON							
3 Pulses / UZS 1000	OFF	ON	OFF							
4 Pulses / UZS 1000	OFF	ON	ON							
5 Pulses / UZS 1000	ON	OFF	OFF							
10 Pulses / UZS 1000	ON	OFF	ON							
20 Pulses / UZS 1000	ON	ON	OFF							
100 Pulses / UZS 1000	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms										
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low				ON						
★ Inhibit level Active High				OFF						
★ Accept UZS 1000 & 2000						ON				
Reject UZS 1000 & 2000						OFF				
★ Accept UZS 5000 & 10000							ON			
Reject UZS 5000 & 10000							OFF			
★ Accept UZS 20000 & 50000								ON		
Reject UZS 20000 & 50000								OFF		
★ Accept UZS 100000									ON	
Reject UZS 100000									OFF	
★ Accept UZS 200000										ON
Reject UZS 200000										OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

(3) High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

L83-UZS8(Pulse/ICT104U)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal High	ON			
Credit-Pulse Normal Low	OFF			
★ Pulse Mode		ON		
ICT104U Mode		OFF		
Disable Inverse Mode			ON	
★ Enable Inverse Mode			OFF	
High Acceptance (Note.3)				ON
★ High Security (Note.3)				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(ICT104U)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ ICT104U Mode		OFF		
Disable Inverse Mode			ON	
★ Enable Inverse Mode			OFF	
High Acceptance (Note.3)				ON
★ High Security (Note.3)				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse	ICT104U
BV1	UZS 1000	UZS 1000
BV2	UZS 5000	UZS 5000
BV3	UZS 10000	UZS 10000
BV4	UZS 50000	UZS 50000
BV5	UZS 100000	UZS 100000
BV6	UZS 2000	UZS 2000
BV7	UZS 20000	UZS 20000
BV8	UZS 200000	UZS 200000