

XBA mini-UAH6

XBA mini Option Switch Settings: 1(Pulse/MDB/ccNet/ICT104V/ICT104U)

Supported bill UAH 1, 2, 5, 10, 20, 50 6bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject UAH 1 & 2	ON											
★ Accept UAH 1 & 2	OFF											
★ Reject UAH 5		ON										
★ Accept UAH 5		OFF										
★ Reject UAH 10			ON									
★ Accept UAH 10			OFF									
★ Reject UAH 20				ON								
★ Accept UAH 20				OFF								
★ Reject UAH 50					ON							
★ Accept UAH 50					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
★ Reserved								ON				
★ Reserved								OFF				
★ Inhibit Active High									ON			
★ Inhibit Active Low									OFF			
★ Reserved										ON		
★ Reserved										OFF		
★ Interface Timing Conversion	50ms LO / 50ms HI									OFF	OFF	
	60ms LO / 300ms HI									ON	OFF	
	30ms LO / 50ms HI									OFF	ON	
	150ms LO / 150ms HI									ON	ON	

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note: (1) Dip switches 1 to 5 are only used for pulse protocol.

(2) Calibrate card.

XBA mini-UAH6(Pulse/MDB/ccNet/ICT104V/ICT104U)

Interface Settings: 2(Pulse) Interface Settings: 2(ccNet)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ 1 pulse / UAH 1			OFF	OFF
5 pulses / UAH 1			OFF	ON
10 pulses / UAH 1			ON	OFF
25 pulses / UAH 1			ON	ON

★ Manufacture setting

INTERFACE	SW1	SW2	SW3	SW4
★ 9600 Baud Rate	ON			
19200 Baud Rate	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
★ ccNet Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD Converter board	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
ccNet Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	ICT104U	ICT104V	ccNet	Pulse	MDB
BV1	UAH 1	UAH 1	UAH 1	UAH 1	UAH 1
BV2	UAH 2	UAH 2	UAH 2	UAH 2	UAH 2
BV3	UAH 5	UAH 5	UAH 5	UAH 5	UAH 5
BV4	UAH 10	UAH 10	UAH 10	UAH 10	UAH 10
BV5	UAH 20	UAH 20	UAH 20	UAH 20	UAH 20
BV6	UAH 50	UAH 50	UAH 50	UAH 50	UAH 50

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
ccNet Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting