

XBA mini-BND3

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill BND 1, 5, 10 3bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	
★	Reject BND 1	ON												
	Accept BND 1	OFF												
★	Reject BND 5		ON											
	Accept BND 5		OFF											
★	Reject BND 10			ON										
	Accept BND 10			OFF										
	Reserved			ON										
★	Reserved			OFF										
	Reserved				ON									
★	Reserved				OFF									
	Disable Bill Reject 4 Times BA Stop By 30 Sec					ON								
★	Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF								
	Stack Banknote when Power-up						ON							
★	Reject Banknote when Power-up						OFF							
	Reserved							ON						
★	Reserved							OFF						
	Inhibit Active High								ON					
★	Inhibit Active Low								OFF					
	Reserved									ON				
★	Reserved									OFF				
★	Interface Timing Conversion	50ms LO / 50ms HI									OFF	OFF		
		60ms LO / 300ms HI									ON	OFF		
		30ms LO / 50ms HI									OFF	ON		
		150ms LO / 150ms HI									ON	ON		

★ Manufacture setting

After setting dip switch of the credit pulses,you should reset the bill acceptor again.

Note : 1. Calibration card is needed.

XBA mini-BND3(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / BND 1			OFF	OFF
	5 pulses / BND 1			OFF	ON
	10 pulses / BND 1			ON	OFF
	20 pulses / BND 1			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	BND 1	BND 1	BND 1	BND 1	BND 1
BV2		BND 5	BND 5	BND 5	BND 5
BV3		BND 10	BND 10	BND 10	BND 10

Interface Settings: 2(ICT104U)

	INTERFACE	SW1	SW2	SW3	SW4
	Reserved	ON			
★	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
★	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting