

BS7-RUB6

BS7 Option Switch Settings: 1 (Special Pulse/ICT004/MDB)

Supported bill Rubles 5, 10, 50, 100, 200, 500 6bills.

BS7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Reject Rubles 5 (Note 1.)	ON							
★	Accept Rubles 5 (Note 1.)	OFF							
	Reject Rubles 10		ON						
★	Accept Rubles 10		OFF						
	Reject Rubles 50 & 100			ON					
★	Accept Rubles 50 & 100			OFF					
	Reject Rubles 200				ON				
★	Accept Rubles 200				OFF				
	Reject Rubles 500					ON			
★	Accept Rubles 500					OFF			
	Reserved						ON		
★	Reserved						OFF		
	Harness Disable							ON	
★	Harness Enable							OFF	
	Inhibit Active High								ON
★	Inhibit Active Low								OFF

◆ Factory configuration has all switches in the OFF position.

Note :

(1) Dip Switch 1 is for Pulse

When SW1 Dip1 is OFF (Accept 5 Rubles),
 Pulse==>5 Rubles=1 Pulse, 10 Rubles=2 Pulses, 50 Rubles=10 Pulses,
 100 Rubles=20 Pulses, 200 Rubles=40 Pulses, 500 Rubles=100 Pulses.

When SW1 Dip1 is ON (Reject 5 Rubles),
 Pulse==>10 Rubles=1 Pulse, 50 Rubles=5 Pulses, 100 Rubles=10 Pulses,
 200 Rubles=20 Pulses, 500 Rubles=50 Pulses.

BS7-RUB6(Special Pulse/ICT004/MDB)

BS7 Interface Settings: 2 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	1 pulse / Rubles 5 (Note 1.)	OFF	OFF		
	2 pulses / Rubles 5 (Note 1.)	ON	OFF		
	5 pulses / Rubles 5 (Note 1.)	OFF	ON		
	10 pulses / Rubles 5 (Note 1.)	ON	ON		
★	50ms LO / 50ms HI			OFF	OFF
	60ms LO / 300ms HI			ON	OFF
	30ms LO / 50ms HI			OFF	ON
	150ms LO / 150ms HI			ON	ON

★ Manufacture setting

BS7 Interface Settings: 3 (ICT004)

	INTERFACE	SW1	SW2	SW3	SW4
	Reserved	ON			
★	Reserved	OFF			
	Pulse Mode		ON	OFF	
	MDB Interface		OFF	OFF	
★	ICT004 Interface		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

BS7 Interface Settings: 3 (MDB)

	INTERFACE	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
★	MDB Interface		OFF	OFF	
	ICT004 Interface		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

BS7 Interface Settings: 2 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	1 pulse / Rubles 10 (Note 1.)	OFF	OFF		
	2 pulses / Rubles 10 (Note 1.)	ON	OFF		
	5 pulses / Rubles 10 (Note 1.)	OFF	ON		
	10 pulses / Rubles 10 (Note 1.)	ON	ON		
★	50ms LO / 50ms HI			OFF	OFF
	60ms LO / 300ms HI			ON	OFF
	30ms LO / 50ms HI			OFF	ON
	150ms LO / 150ms HI			ON	ON

★ Manufacture setting

BS7 Interface Settings: 3 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	MDB Interface		OFF	OFF	
	ICT004 Interface		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	ICT004	Pulse	MDB
BV1	Rubles 10	Rubles 10	Rubles 10
BV2	Rubles 50	Rubles 50	Rubles 50
BV3	Rubles 100	Rubles 100	Rubles 100
BV4	Rubles 200	Rubles 200	Rubles 200
BV5	Rubles 500	Rubles 500	Rubles 500
BV6	Rubles 5	Rubles 5	Rubles 5